

Velcro Cadence Attachment

To attach your Cadence Sensor, please follow these steps:

1) The Velcro strip is longer than it needs to be. You can either trim it or wrap it underneath, keeping the length to accommodate other bikes in the future.

2. To begin, hold the cadence sensor against the chain stay with the long Velcro strip held upwards behind the chain stay. (See fig. 1)

3) At the intersection of the Velcro with the top of the chain stay push the 1" square rubber/hook Velcro pad into the Velcro strap so that the pad will be directly over the top of the stay when the strap is pulled over the top. (See fig. 2)

4) Holding the cadence sensor in place with one hand, pull the Velcro strap, compressing the rubber pad, and attach the Velcro into the front and continue with it behind the cadence assembly. (See fig. 3)

5) After wrapping the Velcro around and under the cadence assembly, trim the length or keep it from dragging in the bicycle spokes.

6) It is advisable to check the tension on the Velcro occasionally to assure it stays tight

